V5 and V8: How to Change the Vend Price

1. Disconnect power to the machine.

2. Open service door.

3. Using a 5/ 16 socket wrench, loosen and remove the chute bolt.

4. Remove the coin chute from the meter case by lifting up and out with extension attached. Place on a flat surface.

5. Remove slide return spring.

6. Remove the slide stop by unscrewing the screw on the underside. The slide stop is the metal plate with a hook, located at the back of the chute where the spring was attached.

7. Pull the slide all the way out and place face up.

8. Unscrew the top two screws on the slide.

9. Turn the slide over and remove the buffer plate.

10. The block out keys are under the buffer plate, remove as needed to adjust the vend price.

8. Follow the directions backwards to replace buffer plate, slide and spring.